

SINCE 1978



OPTICS TECHNOLOGY

Manufacturer & Exporters of : LABORATORY TESTING INSTRUMENTS



An ISO 9001:2008 CERTIFIED
An ISO 10002:2004 CERTIFIED

CE Certified

Tray Dryer



Tray Dryer

Used in pharmaceuticals, chemicals, dyes and food industries for various heating and drying applications.
Electrically operated tray dryer
Double walled construction inner S.S. & outer made of M.S. body duly powder coated.
All the trays are made of S.S. 304.
It is provided with glass wool insulation throughout the chamber fitted with electrical motor with fan with pillow block bearings.
Temp. Controlled By Digital temperature Controller & AIR Circulating Fan For Uniform Temperature.
Tray is made of S.S. 304 and size of the tray is 16" x 32".

For 6 Nos. of trays
For 12 Nos. of trays
For 24 Nos. of Trays
For 48 Nos. of Trays
For 96 Nos. of Trays

OPTIONAL

Microprocessor Based PID Controller
OR

Microprocessor Based PID Controller alongwith PC communication thru built-in RS-485 interface and printing option through software
OR

Touch Screen Display (3,5") system & Pen Drive System alongwith data logging & for saving of data and communication to PC

2/3, DSIDC, Community Works Centre, J-Block, Shakurpur, (Opp. Britannia Ind. Ltd.) Delhi-110034 (India)

Phone: 0091-11-27101383, 27184490, Fax: 0091-11-27108890

E-mail: info@opticstechnology.in, opticstechnology@gmail.com

Website: www.opticstechnology.in