



## TRAY DRYER CE



OT-TD-257-MS



OT-TD-257-SS



OT-TD-257-SS

Used in pharmaceuticals, chemicals, dyes and food industries for various heating and drying applications. Sizes ranges from 6 to 96 trays with heating upto 200°C.

Electrically operated tray dryer is with double walled construction inner S.S. & outer made of M.S. body duly powder coated / S.S. 304. All the trays are made of S.S. 304.

It is provided with glass wool insulation through out the chamber fitted with electrical motor with fan with pillow block bearings. Temp. Controlled By Microprocessor Based PID Controller & AIR Circulating Fan For Uniform Temperature.

### Tray Size

18" x 18"

### Model

### Working Capacity

OT-TD-257/A/6-MS/SS	For 6 Nos. of Trays
OT-TD-257/A/12-MS/SS	For 12 Nos. of Trays
OT-TD-257/A/24-MS/SS	For 24 Nos. of Trays
OT-TD-257/A/48-MS/SS	For 48 Nos. of Trays
OT-TD-257/A/96-MS/SS	For 96 Nos. of Trays

### Tray Size

24" x 24"

### Model

### Working Capacity

OT-TD-257/B/6-MS/SS	For 6 Nos. of Trays
OT-TD-257/B/12-MS/SS	For 12 Nos. of Trays
OT-TD-257/B/24-MS/SS	For 24 Nos. of Trays
OT-TD-257/B/48-MS/SS	For 48 Nos. of Trays
OT-TD-257/B/96-MS/SS	For 96 Nos. of Trays

### Tray Size

16" x 32"

### Model

### Working Capacity

OT-TD-257/C/6-MS/SS	For 6 Nos. of Trays
OT-TD-257/C/12-MS/SS	For 12 Nos. of Trays
OT-TD-257/C/24-MS/SS	For 24 Nos. of Trays
OT-TD-257/C/48-MS/SS	For 48 Nos. of Trays
OT-TD-257/C/96-MS/SS	For 96 Nos. of Trays

### Optional :

- Digital Timer
- Microprocessor Based Touch Screen Display System with Pen Drive for Data Logging, Printing Through PC Communication and saving of Data in PC
- 21 CFR Software (for Non-Editable Data)