



OPTICS TECHNOLOGY



SINCE 1978

Manufacturer & Exporters of : LAB TESTING INSTRUMENTS



An ISO 9001:2015 CERTIFIED IEC 61010-1:2010
An ISO 10002:2018 CERTIFIED BS EN 12469:2000
An ISO 13485:2016 CERTIFIED ISO 29463-5:2022

DIGITAL GRAIN MOISTURE METER CE

(LCD DISPLAY)



OT-DGM-12

Digital Grain Moisture Meter is an advanced digital moisture measuring device having automatic moisture measurement of a wide variety of agriculture grains. It has the most advanced revising mode and user-friendly material type selection mode. It has automatic temperature adjustment and moisture correction when no material is measured. It works on AA batteries and has automated power shut down feature. It ideally is used for moisture measurement in agricultural grains like wheat, soybean, beans sediment, coffee beans, rice, etc.

Measuring Element	Grain
Display	LCD
Moisture Range	3% to 35%
Repeating Error	≤ 0.2 %
Measuring Error	≤ ± 0.5 %
Measuring Time	≤ 10 seconds
Working Temperature	0 °C to 40 °C
Working Power	4 pcs × 1.5 V AA batteries

2/3, DSIDC, (Behind Fun Cinema) NSP, Pitampura, Delhi-110034 (INDIA)

☎ 9811238150, 9811238151, 9811236960

E-mail: info@opticstechnology.in,

opticstechnology@gmail.com,

Website : www.opticstechnology.in