



CRUSH RESISTANT TESTER (DIGITAL) CE



Crush Testers are designed for performing Ring Crush Test (RCT), Edge Crush Test (ECT), Flat Crush Test (FCT), Pin Adhesive Test (PAT), Concora Medium Test (CMT), Corrugated Crush Test (CCT) and other general compression tests, on a variety of materials like paper, paperboard etc.

These multi-functional equipments incorporate high accurate load cell and precise ball screw, which drives the compression platen steadily along the guide track to compress the specimen.

Applications:

- Paper
- Paper Board
- Corrugated Board
- Duplex Cartons

Technical Details :

Capacity	: 0 to 500 Kgf., 0 to 2000 Kgf. with 0.1 Kg. least count digital display
Speed	: 5 mm / min.
Motor	: ½ HP, 1425 rpm single phase induction motor
Power required	: 220 / 440V AC, 50 Hz's and Single Phase